


SIHOO
PRODUCT
INSTALLATION
GUIDE

B100-B10



Scan the code to watch the
product installation video



Company: Shenzhen Sihoo Intelligent Home Co., Limited

Company Address: Building #A, Yuyuan Industrial Park, Baoan District,
Shenzhen City, Guangdong Province, China

Manufacturer: FoShan Kezhimei Home Co., Limited

Manufacturer address: Jiujiang Town, Nanhai District, Foshan City,
Guangdong Province, China.

Company Website: www.sihoo.com/en

www.sihoo.com/en



Assembly Introduction


(The size will be according to regular measurements)

1	2	3 Note: If your model does not have foot pedals, you can skip this step.
Insert the 5 casters into the base, then place the gas lift cylinder into the center hole of the base.	Attach the backrest to the backrest connector using 2 pcs of M8*30 screws.	(For models with footrest only) Loosen the hex screw on the footrest tube and pull the tube out from the seat cushion. Then, flip the footrest tube over.
4 Note: If your model does not have foot pedals, you can skip this step.	5 Note: Please distinguish between left and right armrests and ensure correct front/back orientation.	6
Reinsert the flipped footrest tube into the holes on both sides under the seat cushion. Tighten the hex screw securely.	Part 1: Use 2 pcs of M6*30 screws with 6mm washers. Part 2: Use 4 pcs of M6*35 screws with 6mm washers. Attach the armrests to the seat cushion	Connect the seat plate to the seat cushion using 4 pcs of M6*20 screws with 6mm washers.
7	8	9
Align the four screw holes and secure the backrest to the seat plate using 4 pcs of M8*20 screws.	Place the seat assembly onto the gas lift cylinder to connect the seat with the base.	Insert the headrest into the designated holes on the backrest. Then, attach the backrest cover by snapping it into place, ensuring correct top/bottom orientation. Assembly is now complete.



Functions

(The size will be according to regular practice)



Installation Instruction

- Before installation, please read all the safety instructions below (drawings) carefully and master the installation steps and methods.
 - Counting the parts is complete or not, if there is any breakage.
 - To avoid injury, it is recommended that you wear gloves during installation.
 - Please choose a spacious and clean flat floor for installation, and then lay the paper sleeves on the ground, to avoid collision between components and the ground.
 - To avoid using the wrong screws, please fix all the screws before tightening them.
 - Please note that once the gas lift is installed, it is difficult to remove.
- If you need to disassemble the chair, such as moving, please gently tap the head of the gas lift with a rubber-tipped hammer several times, and then remove the base. After that, continue to gently tap the base, using the principle of vibration to make the gas lift fall off. Please be careful not to get hurt as tools are needed to do this.
- (Damage and accidents caused by this operation do not fall within the scope of product warranty, please careful operation.)

Precautions For Use



- Please note that this product is designed for one person, one chair is for one person only.
- For the use of product features, please follow the instructions in the product features display.
- Make sure all screws and components are locked tightly before using this product and check it at least once every 3 months.
- Please use on the flat floor, avoid wet or fireworks places, avoid long time direct sunlight.
- Don't use sharp or hooked objects to scrape the chair and do not get it close to the fire.
- Not allowing the child under 5 years old to sit on the chair alone.
- Please don't sit on the armrest, stand on the chair or use it as a ladder or footsteps, in case cause some danger.
- To avoid any harm to your fingers don't insert them into the mechanism while sitting.
- For your safety, no disassembly to the gas lift is allowed.



Parts List

(The size will be according to regular measurements; One more as a backup)

Casters x5	Base x1	Gas Lift Cylinder x1	Armrests x1 pair	Backrest x1
Seat Plate x1	Backrest Connector x1	Headrest x1	Backrest Cover x1	Backrest Cover x1
M8x30 Screws x2 (+1 spare)	M8x20 Screws x4 (+1 spare)	M6x30 Screws x2 (+1 spare)	M6x35 Screws x4 (+1 spare)	M6x20 Screws x4 (+1 spare)
6mm Washers x10 (+1 spare)	Optional Parts Seat Cushion (without footrest)	Note: Screws are pre-installed on the footrest tube. Seat Cushion (with footrest assembly)		

Note: Before installation, pls classify the screw, measure the screw length to easy assemble.